

Snowball

Design by
Trond Svendgård



User manual




Gebrauchsanweisung



Mode D'emploi



Bruksanvisning



Northern

Snowball portable table lamp



Input: 5.0V – 3A

3 W step dimmable LED, 158 lm, 2700K, CRI>90

3.7V Lithium Ion rechargeable battery, IP44

Caution

1. Read this manual carefully before use and keep it safe for future reference.
2. Designed for indoor use. Must be stored indoors. Outdoor use demands protection from direct rain.
3. Keep this product away from children. Do not leave children unattended near this product.
4. Be careful not to overtighten or improperly fix the threaded glass globe.
5. The lamp must not be in touch with water, humidity, gas or caustic materials.
6. This product is water resistant, not waterproof. Don't leave it outside without supervision, overnight or in rain.
7. Luminaire should not be covered with any objects.
8. Place the lamp on a level and smooth surface.
9. Don't pull or hang the lamp by the charging cable.
10. Do not stare directly at the operating light source.
11. Do not expose luminaire to excessive heat or prolonged direct sunlight. Only use the included battery.
12. The lamp shall only be charged with rated voltage.
13. Don't recharge the lamp if the powercable or plugs are damaged. To avoid hazard, only the manufacturer, his service agent or a similar qualified person may repair and replace damaged parts.
14. It is very unlikely, but all batteries may leak harmful chemicals. To avoid risk of injury, do not let any material leakage from a battery come in contact with eyes or skin.


Charging the battery

1. To charge the battery use the included USB cable. Plug the USB-C cable into the lamp and connect to a computer or a universal USB adaptor (not included). The specifications of the adaptor may affect the battery charging time. Be careful with the USB-port in the lamp when inserting the cable to avoid damage.
2. While charging a red indicator light near the charging port will light until fully charged. It will turn green when fully charged.
3. To fully charge an empty battery takes approximately 6-8 hours.
4. Always insert the rubber protection cap in the charging port after charging.

Cleaning instructions

1. Wipe spills and stains immediately.
2. Clean using a soft, dry cotton cloth.
3. If a deeper clean is required, a cotton cloth moistened with lukewarm water can be used. Always wipe with a dry cotton cloth to remove any residue.
4. Avoid applying strong cleaning agents as it may damage the surface.

Instructions for use



Northern

Contact info

Northern.no AS
Bygdøy allé 68
0265 Oslo, Norway

Phone: +47 40 00 70 37
Email: post@northern.no
Web: northern.no

Facebook: northern.no
Instagram: northern.no
Pinterest: northernoslo

More information about our
products and updated user
manuals are available on
our website.

Northern