
# PANTOP Ø18 PORTABLE LAMP Assembly Instruction



#### Before you get started



Charging: Charging time: 6h, light hours at max. setting: 8h. Fully charge the battery before the first use. A small red LED light on the side indicates charging; a green LED means it is fully charged. Disconnect the charger once fully charged. Charge the lamp indoors. Do not leave unattended when charging. Old batteries are replaceable by a professional; disconnect the lamp from the charger before disassembly. Use only official LG Battery, model INR18650MH1 Li-lon battery 3.70V 3200 mAh. Dispose of the old battery according to the local regulations.


Usage: The luminaire can be used outdoors but should be stored indoors.

Cleaning: Turn off the lamp. Wipe off dust with a dry, soft cloth. If needed, clean with a soft cloth dampened in lukewarm water with a mild detergent without abrasives, solvents, alcohol or acid. Water must have evaporated before the lamp is switched on again.

Safety: If the lamp, cable or battery is damaged (e.g., swelling, cracks, leakage), it feels hot or emits unusual odors stop using immediately. This product contains a lithium-ion battery. Improper handling may cause fire, explosion or injury, handle with care. Verpan A/S will not take any responsibility for accidents that occur due to replacing the original parts with an incorrect battery or light source.

Specifications: 3W LED board, 2700 K, CRI >80, IP44, Class III.

#### Box contains:




#### You will also need:



USB-A SELV charger 5V === 2A


## When replacing an old battery you will also need:










Philips Screwdriver






### Replacing an old battery.









Egeskovvej 29 | 8700 Horsens | Denmark info@verpan.com | verpan.com

Supplier fsc logo is placed here. Black with no background width: 17mm