



# User Manual



**Alarm Clock**

Jacob Jensen




**Congratulations on your new Jacob Jensen® product.**

Jacob Jensen embodies the honesty and simplicity of our founder's vision, focusing on the essentials of the product experience. Your new purchase pushes the boundaries of everyday objects, combining function with meaningful design.

Created with our principles of Distance, Closeness, and Touch, this product reflects our long design legacy, enhancing everyday life through thoughtful design.

We hope you will enjoy an elevated experience. For more information, visit [jacobjensen.com](https://jacobjensen.com).




Product by  
F&H Group A/S  
Gl. Skivevej 70  
8800 Viborg  
Denmark

English

Read the instructions included in this  
user manual before using the Alarm  
Clock and save it for future reference.

|                                     |   |
|-------------------------------------|---|
| <b>1. Safety Instructions</b>       | 3 |
| <b>2. Product Overview</b>          | 4 |
| <b>3. Using your Alarm Clock</b>    | 5 |
| 3.1 Getting started                 | 5 |
| 3.2 Setting the alarm               | 5 |
| <b>4. Mounting your Alarm Clock</b> | 7 |
| <b>5. Care and Maintenance</b>      | 7 |
| 5.1 Low Battery Warning             | 7 |
| <b>6. Troubleshooting Guide</b>     | 8 |
| <b>7. Disposal Guide</b>            | 8 |




We recommend that you read this user manual carefully. It contains instructions on how to use your new purchase correctly and how to maintain its functionality with regular use.

Jacob Jensen and our partner F&H Group A/S reserve the right to make improvements to enhance the product experience without prior notice.

The instructions and illustrations in this manual are not binding and may change as the product evolves.

For more information, visit [jacobjensen.com](http://jacobjensen.com) or contact our partner, F&H Group A/S, at [info@fh-as.dk](mailto:info@fh-as.dk).



## 1. Safety Instructions

- Do not ingest the batteries, as it may cause chemical burns.
- If the button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children.
- If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

**Save these instructions.**




This mark on a product and/or accompanying documents indicates that when it is to be disposed of it must be treated as Waste Electrical & Electronic Equipment (WEEE). Any WEEE marked waste products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used. For proper treatment, recovery and recycling; please take all WEEE marked waste to your Local Authority Civic waste site, where it will be accepted free of charge. If all consumers dispose of Waste Electrical & Electronic Equipment correctly, they will be saving valuable resources and preventing potential negative effects upon human health and the environment from hazardous materials that the waste may contain.



This product is CE marked in accordance with applicable EU legislation. The CE marking confirms that the product complies with all relevant health, safety, and environmental protection requirements set by the EU.


The CE marking means that the product has been assessed and tested to ensure it can be safely used in EU countries and complies with EU directives for electrical and electronic equipment. For more information about specific product requirements, please contact the manufacturer.



## 2. Product Overview


### Front


- A.** Time (24h or AM/PM available)
- B.** Date
- C.** Magnetic table stand
- D.** Light/Snooze  
Press to activate display light.  
During alarm, press to activate snooze function.
- E.** Alarm set and activated
- F.** Alarm On/Off button



### Back (without cover)





- G.** Alarm Set  
Press to adjust wake up time.
- H.** Volume Adjust  
Choose between high or low alarm volume.
- I.** Clock Set  
Press to adjust date and time.
- J.** Battery Compartment  
Uses 2 CR2450 button cell batteries. Placed with '+' upwards.
- K.** Step Up/Down and Daylight Saving Time (DST)  
Press and hold both buttons for 3 sec. to turn Daylight Saving Time on or off.
- L.** Alarm Tune Selector  
Choose between three alarm tones.





## 3. Using your Alarm Clock



### 3.1 Getting Started

1. Insert batteries. The first time you use the Alarm Clock a message on the screen will prompt you to insert batteries. Remove the magnetic back cover by placing your fingernail in the small groove on the bottom edge and lifting the cover off. Here you can insert two CR2450 button cell batteries.
2. Enter Time Setting Mode. Press  once and the screen will guide you through setting year, day, time format and time.
3. Choose correct setting. Use  /  to choose the correct setting and press  again to save step and move on to the next setting.

**Note:** If you choose 12-hour format, "AM/PM" will be displayed on the screen.


While in Time Setting Mode, if no buttons are pressed for 20 seconds, the Alarm Clock will exit the setting mode automatically.


4. Activate Daylight Saving Time – only for European citizens.




To set the Alarm Clock for Daylight Saving Time (DST) press and hold  /  for 3 seconds. Now DST will show at the bottom of your display. This means that the time automatically jumps one hour forward on the last Sunday of March and one hour backwards on the last Sunday of October.



Now the time is set, and you are ready to set your alarm.



### 3.2 Setting the Alarm

1. Enter Alarm Setting mode. Press  to enter the Alarm Setting Mode. The default alarm time is set for 7.15 and will be seen on the display if activated.





2. Set new alarm. Use the  /  buttons on the sides to choose the time you want the alarm to sound, confirming each step by pressing the .

**Tip:** For quicker adjustments, press and hold the  /  button for more than 2 seconds. This will advance the number by 3 steps for hours and 5 for minutes.

3. Activate alarm. Press  once on the right side of the alarm clock. The set alarm time will be displayed under the  on the display alongside the current time and date.

**Note:** If no alarm is displayed on the screen, it means no alarm is activated.







4. Turning off the alarm. Press  to turn off the alarm when it goes off. The alarm will sound again at the set time the following day. To deactivate the alarm completely press  again.


5. Snoozing your alarm. You can push  to snooze the alarm for 9 minutes.

**Note:** If the alarm is not turned off, it will automatically stop after ringing for 2 minutes, in order to save battery power.

## Alarm Tones

Select one of three specially designed tones to wake you by toggling the button (see product overview):


-   Sunshine Melody – A special composition to wake you gently
-   Forrest Birds – Birdsong from the Danish forest.
-   Beep Up – A comfortable series of beeps

To test the sounds you press the  button for a couple of seconds while the alarm tone toggle is set to each option.

## Volume Level

Choose between two volume levels by using the switch on the back (see product overview).





## 4. Mounting your Alarm Clock


### Table Stand

Your new Alarm Clock comes with a magnetic table stand, which lets you easily place it on a table or nightstand.

### Wall Mounting

The Alarm Clock also comes with a magnetic wall bracket, which can be fixed to a smooth vertical surface using the included adhesive pad, or Ø3mm screws appropriate for the material to screw into.

### Wall Bracket




**N.B.:** When placing the adhesive pad and mounting the bracket, ensure that the side with the Jacob Jensen logo faces **away** from the wall.

## 5. Care and Maintenance

### 5.1 Low Battery Warning

When the battery is low, the display on the Alarm Clock will show a low battery warning.

- First warning: The warning will appear approximately one month before the battery is fully depleted – when the voltage drops to around 2.8V. The warning repeats every 2 hours.



- Second warning: When the voltage drops to 2.75V, the warning will appear every five minutes.
- Third warning: When the voltage drops below 2.7V, you will get a message on the clock telling you the Alarm Clock is out of power and the batteries need to be changed.

## 6. Troubleshooting


If you experience slow operation of the Alarm Clock try one of these actions:

- Remove the batteries and wait 10 seconds before inserting them again and let the Alarm Clock load.
- Avoid pressing the keys continuously if the device responds slowly. Wait a few seconds before pressing the keys again.
- Occasionally, the display will flash white. This means the Alarm Clock is refreshing the display to make sure it is clear and that the time is easy to read.

## 7. Disposal Guide

When your product is no longer usable, dispose of it responsibly, keeping the environment in mind.

- Proper disposal helps conserve resources and prevents harm to health and the environment from hazardous materials.
- Electronic equipment must be disposed of as Waste Electrical and Electronic Equipment and should not be mixed with household waste.
- Take your old appliance to a Local Authority Civic Waste Site for proper sorting and processing.



## Warranty

In accordance with the EU Consumer Sales Directive (1999/44/EC), you, as a consumer, have the right to make a warranty claim for 2 years from the date of purchase if the product has any faults or defects that are not caused by improper use. If the product is found to be defective within this period, you are entitled to a repair, replacement, or, in some cases, a refund.

To claim your warranty, please contact the retailer where the product was purchased or the manufacturer, if specified in the warranty terms.

The warranty does not cover damage caused by misuse, accidents, or normal wear and tear.



The manufacturer declines all liability for damage to persons or property caused by:

- Use of the appliance other than the one envisaged.
- Not having read the user manual.
- Tampering with any part of the appliance.
- Use of non-original spare parts.
- Not following the safety instructions.