


Quick guide



Coffee Press
w/CoffeeCatcher™

Jacob Jensen



Read this booklet
before using and save it
for future reference.

English

Know your Coffee Press	4
Using your Coffee Press	6
How to use CoffeeCatcher™	9

Know your Coffee Press

A Spout


B Plunger grip

C Handle

D Plunger
with filter and holes for
easy rinsing.

E Jug
Double walled glass, for
insulating effect.

F CoffeeCatcher™
Pull out for easy
removal of coffee
grounds, before rinsing.



Using your Coffee Press

How to Use

1. Remove the plunger along with the lid. As you lift it out, you will see the CoffeeCatcher™ positioned at the bottom of the Coffee Press. Leave it in place.
2. Add your preferred amount of ground coffee and pour in hot water.
3. Align the hole at the bottom of the filter with the CoffeeCatcher™ rod and gently press the plunger down.
4. Let the coffee steep for approx. 4 min, then press down fully and enjoy your fresh brew.

Good to know

The duration of time you should let the coffee beans and water sit, steep time, before pushing down the plunger can vary depending on the specific type of coffee and your personal preference. We recommend that you experiment a little to find your perfect brew.

The insulated body not only keeps your coffee warm, but is also safe to touch, providing a more comfortable experience.



How to use CoffeeCatcher™

The Coffee Press is designed for effortless cleanup, thanks to the CoffeeCatcher™.

Once you have poured out the last coffee:

1. First, remove the plunger, leaving the CoffeeCatcher™ at the bottom with the compressed coffee grounds.
2. Grab the ribbed end of the CoffeeCatcher™ rod and simply pull out the CoffeeCatcher™ in one smooth motion to remove the grounds effortlessly.
3. Tap the CoffeeCatcher™ against the edge of the waste bin to dispose of the grounds, or recycle the used coffee grounds as desired.

Rinse everything and your Coffee Press is ready for another brew.



For additional product documentation,
please visit jacobjensen.com
Scan the QR code for quick access.

- UK A complete user manual can be found on our website at jacobjensen.com. Scan the QR code for quick access.
- DK En komplet brugermanual kan findes på vores hjemmeside på jacobjensen.com. Scan QR-koden for hurtig adgang.
- SE En komplett användarmanual finns på vår hemsida jacobjensen.com. Skanna QR-koden för snabb åtkomst.
- NO En komplett brukermanual finner du på vår nettside på jacobjensen.com. Skann QR-koden for rask tilgang.
- NL Een volledige gebruikershandleiding kunt u vinden op onze website jacobjensen.com. Scan de QR-code voor snelle toegang.
- FR Un manuel d'utilisation complet est disponible sur notre site Web à l'adresse jacobjensen.com. Scannez le code QR pour un accès rapide.
- DE Eine vollständige Bedienungsanleitung finden Sie auf unserer Website unter jacobjensen.com. Für schnellen Zugriff scannen Sie den QR-Code.



Product by
F&H Group A/S
Gl. Skivevej 70
8800 Viborg
Denmark

Jacob Jensen

Version 01.2025